

Hologram: Modem & SIM Tests

Important Note: Before you begin, please ensure your SIM is successfully activated in the Hologram Dashboard!

Modem Module & SIM Diagnostics Procedure

Using your favorite terminal program (Teraterm, Putty, GTKTerm, etc.), do the following:

1. RUN THE FOLLOWING COMMANDS AND RECORD THEIR OUTPUTS

```
AT
ATI
AT+CGMI
AT+CGMM
AT+GMM
AT+CPIN?
AT+CCID
AT+CRSM=176,28539,0,0,12
AT+CFUN?
```

2. RUN THE FOLLOWING COMMAND UNTIL THE RESPONSE READS SOMETHING OTHER THAN "+CSQ: 99,99"

```
AT+CSQ
```

3. RUN THE FOLLOWING COMMANDS AND RECORD THEIR OUTPUTS (NOTE, THE LAST COMMAND, BELOW, MAY TAKE UP TO 3 MINUTES TO COMPLETE)

```
AT+CREG?
AT+CGREG?
AT+CGDCONT?
AT+CGACT?
AT+COPS?
AT+COPS=?
```

4. SEND THE OUTPUTS FROM THE ABOVE COMMANDS IN STEPS 1 & 3 VIA EMAIL TO: SUPPORT@HOLOGRAM.IO